

ATARI SUPER SKETCH ADDENDUM SHEET

The following are helpful hints for operating your Atari SUPER SKETCH.

SYSTEM MEMORY REQUIREMENTS:

Your Atari computer must have at least 48K Bytes RAM installed to operate SUPER SKETCH SOFTWARE.

DISK DRIVE USAGE:

1. Power On- If you plan on using disk storage, you must power your system up with DOS available in the disk drive. Before turning on the console, place a disk with DOS present in the powered disk drive. Then turn on the console. SUPER SKETCH will then load the necessary DOS disk utilities while it initializes the system. The DOS disk can be removed and replaced with your picture disk when the SUPER SKETCH banner becomes visible on the screen.
2. Disk Capacity - An empty formatted disk can store up to ten (10) pictures created on SUPER SKETCH. The system will not tell you when your disk is full. If you cannot get your disk to accept a save, it is probably full. If this is true, simply place a new disk in the drive, and format it using the SUPER SKETCH format utility. You may now save your picture to this clean disk.
3. BRUSH and DESIGN Storage - The BRUSH and DESIGN menus are stored along with your picture even though they are not immediately visible. This special feature allows you to store your favorite custom brushes and painting patterns for use in future art. To use them, simply load the picture that was stored with your library of custom brushes and designs. After you clear the screen, your patterns are ready for use in a new picture.

ACTIVE COMMANDS:

The GRAPHICS MASTER software written for SUPER SKETCH is like any other computer software in that it will do--WHAT YOU TELL IT TO DO! Be careful to choose the features that you want to be active and be sure they are highlighted when you return to your drawing. Most features (like SWAP, FILL, Special Brushes or Designs, etc.) will remain active until you select a new feature or pattern which replaces the previous entry.

If you wish to insure that certain features are turned off, follow these simple hints:

- * Examine each menu to see which features have a Highlighted first character. These features are active.
- * To turn off expert functions, select the word EXPERT on the expert menu.
- * To turn off SWAP, FILL, EXPERT functions, select DRAW.
- * The standard small brush is in use when the word BRUSH in the main menu is not highlighted. Any other brush will cause this word to be highlighted.
- * The standard solid Design is in use when the word DESIGN in the main menu is not highlighted.